

User Manual ► FEISOL Monopod CM-1401**A. Change from 1/4" to 3/8" attachment screw of the main base**

In order to attach a ball head or other accessory to the CM-1401 Monopod for different size of equipment (1/4" or 3/8"), use the included 3/4" socket-wrench to loose the 3/4" nut in the middle of the base. Undo the stud with your hand. Reattach the stud upside-down will reveal a 3/8" thread at its other end. Install removed 3/4" nut to tighten stud in position.

Caution! Take measurement that you don't damage your equipment (thread hole).

